



RECESSED ADDRESS LIGHT INSTALLATION INSTRUCTIONS

Installation is to be by a qualified electrician in accordance with all applicable electric codes.

1. Recessed address light by TWO HILLS STUDIO. Actual shape may vary. This fixture is only for installation in a masonry wall or post.
2. Provide appropriate size masonry opening in wall or post (Refer to fixture cut-sheet).
3. Power supply by others. Turn off electricity to power supply by others before installing address light.
4. Connect ground wire from power supply to the ground wire of the address light.
5. Connect black & white wires from power supply to corresponding black & white wires from address light using appropriate wire nuts.
6. Tuck all wires into the junction box provided with the fixture with removable cover plate & reinstall cover plate.
7. Install provided plastic masonry anchors into masonry wall or post to align with mounting holes on address light.
8. Install address light to masonry wall or post opening with provided brass mounting screws.
9. Front glass panel is removable for relamping.
10. Do not exceed wattages indicated on the fixture.
11. Fixtures are for 120 volt power supply unless labeled otherwise. Connect only to a power supply of the proper voltage.