



HANGING LANTERN FIXTURE INSTALLATION INSTRUCTIONS

Installation is to be by a qualified electrician in accordance with all applicable electric codes.

1. Light fixture by TWO HILLS STUDIO. Actual shape may vary.
2. Attach universal bracket provided with fixture to junction box with threaded screws pointing down.
3. Electrical junction box in ceiling by others. Turn off electricity to electrical box before installing the fixture.
4. Connect ground wire from junction box to the green ground screw on the universal bracket or to a separate ground wire on the fixture if provided.
5. Connect black & white wires from fixture to corresponding black & white wires from junction box using appropriate wire nuts. Tuck the wires into the junction box.
6. Fasten the fixture canopy to the threaded screws on the universal bracket with knurled lock nuts and balls or nuts provided. Secure these joints with Loctite 262 liquid threadlocker (Provided) to prevent loosening of fixture due to wind or vibration. Rotate universal bracket on the junction box as needed for proper alignment of the fixture.
7. Pendant sleeve with threaded pipe inside. If pendant is shipped loose from fixture, attach the threaded pipe to the coupling on top of the fixture and to the canopy with lock nuts and lock washers provided. Secure these joints with Loctite 262 liquid threadlocker (provided) to prevent loosening and rotation of fixture due to wind or vibration.
8. In most models either the top or bottom of the fixture is open for relamping. In other cases a hinged panel is provided. Use only bulbs indicated on the fixture.
9. Fixtures are for 120 volt power supply unless labeled otherwise. Connect only to a power supply of the proper voltage.